



RealWear HMT Voice Commands for Onsight Connect

This document outlines the operational voice commands currently available in Onsight Connect for RealWear version 8.1.209.

Document Revision**Librestream****RealWear HMT Voice Commands for OnSight Connect**

January 2018

Information in this document is subject to change without notice.

Reproduction in any manner whatsoever without the written permission of Librestream is strictly forbidden.

Copyright © 2006–2018 Librestream Technologies, Incorporated.

All rights reserved.

Name of Librestream Software OnSight Connect

Copyright Notice: Copyright 2004–2018 Librestream Technologies Incorporated. All Rights Reserved.

Patents Notice: United States Patent # 7,221,386, together with additional patents pending in Canada, the United States and other countries, all of which are in the name of Librestream Technologies Inc.

Trademark Notice: Librestream, the Librestream logo, OnSight, OnSight Connect, OnSight Mobile, OnSight Enterprise, OnSight License Manager, OnSight TeamLink, OnSight Account Manager and OnSight Management Suite are either registered trademarks or trademarks of Librestream Technologies Incorporated in Canada, the United States and/or other countries. All other trademarks are the property of their respective owners.

RealWear HMT Voice Commands for OnSight Connect

This document outlines the operational voice commands currently available in OnSight Connect for RealWear version 8.1.209.

To access the OnSight software on your HMT from the Home screen say, “*My Programs.*” On the programs listing, you should see the *OnSight* icon. You can then say either “*Select Item #*” using the number assigned to that icon or simply, “*OnSight.*”

If this is the first time running OnSight on the HMT, you will need to login and set the “*Remember Me*” button to establish your auto-login credentials. OnSight will also ask you to grant it permission to access the HMT’s location, camera, microphone, etc. Please allow and check the ‘Do not ask again’ boxes.

First Time Login: From the Login Screen

- a. Set Username
- b. Set Password
- c. Toggle Remember Me
- d. Login
- e. View Terms
- f. Show/Hide Settings
- g. Forgot Password

For Subsequent Logins

If previously configured, OnSight Connect should start, auto-login and register its services. System Health indicates whether all the necessary services have been connected. If System Health is green, you may proceed. If it is not, you will NOT yet be able to make or receive calls until the network problem is resolved. Once fully logged-in and System Health is green, you may select the contact you want to call or wait for an incoming call. To answer an incoming call, simply say, “*Accept.*” To initiate a call, open Contacts and select the individual you want as stated below:

1. For Contacts
 - a. Show/Hide Contacts
 - b. Scroll Up/Scroll Down
 - c. Select Item # (to select a specific contact)
 - d. Speak the username as listed in the contact to initiate a call

2. From Viewfinder

- a. Disconnect call
- b. Start/Stop Streaming
- c. Start/Stop Recording
- d. Take Picture
- e. Share picture/Stop sharing picture
- f. Share file/Stop streaming (for video only)
- g. Telestrate circle/arrow
- h. Erase telestration
- i. Toggle mic (toggles mic for OnSight only)
- j. Toggle torch
- k. Zoom level 1-3
- l. Show Contacts
- m. Show Files
- n. Show settings
- o. Show System Health
- p. Show info (OnSight Help)

3. File System

- a. Show Files
- b. Scroll up/down (if multiple rows)
- c. Select item # (to choose image or video files)
- d. For sharing images
 - i. Share File
 - ii. Stop sharing file
 - iii. Email file
 - iv. Delete file
 - v. Toggle properties
 - vi. Close (when viewing but not sharing image)
- e. For sharing videos
 - i. Play file
 - ii. Exit playback
 - iii. Email file
 - iv. Delete file
 - v. Toggle properties
 - vi. Close (when viewing but not sharing video)

4. Universal Commands (RealWear commands available within OnSight)
 - a. Show Help
 - b. Navigate Home
 - c. Navigate Back
 - d. My controls
 - e. Recent applications
 - f. Mute microphone (mutes mic for all programs)

5. Select Item #
 - a. When moving to a new screen, all selectable items will be numbered.
 - b. The command “Select Item Number” will simulate a mouse-click on that item.
 - c. In many cases, such as a list of pictures or videos, “Select Item #” will be the only way to select a specific item for sharing or playback.

TIPS

1. Your best friend will be the “Show Help” button on any screen within OnSight will bring up the menu of available commands in that area throughout the application. However, do keep in mind that the current duration of the help menu on the screen is four seconds.

2. If your HMT-1 will be idle and you do not want it listening for commands, which may occur unintentionally due to voices in the room, use the command “Mute Microphone.” This is an HMT-1 command that stops the device from listening and presents you with a dialogue instructing you to “Press ACTION button to reactivate microphones.” The ACTION button is next to the power button. When you press this ACTION button, the device will again, “Start Listening.”